


Foam Cushion Installation for Digital Projection Television Model WD-65000

This foam cushion has been provided for the enhancement of your viewing pleasure, and its installation is optional. We recommend that you install the foam cushion if your TV is on a low-pile or non-carpeted floor. When installed, the foam cushion should lower the noticeable sound level from the internal fan. Below are the installation instructions for the foam cushion. If you have questions regarding its installation or use, please contact your authorized Mitsubishi dealer.

Installation Instructions

Compress the foam cushion and wedge it between the front lip of the TV cabinet and the floor. For maximum effectiveness, the foam cushion should be centered under the TV cabinet and approximately 1" from the front edge of the TV cabinet.



Designed and Printed in the U.S.A.